Don't get printed hair extensions wet.
- Do not swim or bathe with printed extensions.
- Do not handle printed hair extensions with wet hands.
- Do not put printed hair extensions in mouth.
Works with inkjet printers only.
Not for use in laser printers or copiers, may cause damage.
Do not reattach hair extensions to the paper after use.
Inkjet inks (not included) may stain fabrics and other surfaces.
Avoid contact with carpet, clothing, walls and furniture.
Colors and decorations may vary from those shown.
Hair streak on doll is permanent.

6+ *Barbie* ® **INSTRUCTIONS** MATTEL ®

W4504-0920
X0428

HINTS & TIPS
• If hair is not stuck completely to the paper, don't use it. Please contact Mattel
   Consumer Relations.
• If you print on the wrong side by mistake, turn the paper over and print again.
• Don't rub printed hair extensions.
• Store hair extension sheets in a flat position in a cool, dry place.
• Use only barbie.com/designablehair for printing on hair extension sheet.
• For best results, use "normal" print quality. See your printer manual for details.
• For jams or any other printer issues, consult your printer manual or contact your
   printer's manufacturer.
• The sample hair extension on the package is not for printing.

Intel® is a trademark of Intel® Corporation in the U.S. and/or other countries.
Adobe® and Flash® are either registered trademarks or trademarks of Adobe® Systems
Incorporated in the United States and/or other countries.
Mac is a registered trademark of Apple Inc.

CONSUMER INFORMATION

Need Assistance? Visit service.mattel.com or call 1-888-892-6123
(US and Canada only).

SERVICE.MATTEL.COM

Contents: Please remove everything from the package and compare to the contents shown here. If any items are missing, please contact your local Mattel office. Keep these instructions for future reference as they contain important information.

©2011 Mattel, Inc. All Rights Reserved.

1. Go to *www.barbie.com/designablehair* and design your hair extension.

2. Do a test print on regular printer paper (not included).

3. Remove all other paper from your printer.

4. Unfold the hair extension sheet, remove the wax paper, and load into your printer.

ⓐ If your printer feeds from the top, load hair extension sheet with hair side facing you as shown. Magenta arrows should point toward the printer.

ⓑ If your printer feeds from the bottom, load hair extension sheet with cover side facing you as shown. Blue arrows should point toward the printer.

ⓐ Top-feed   Or   ⓑ Bottom-feed

Works with inkjet printers only.

5. Click 🖨 , then click "Print" or "OK" on the printer dialog window that appears.

**6.** Allow the ink to dry (drying time varies). Peel hair extension off and attach to a clip.

ⓐ Peel hair extension from the paper.   ⓑ Attach to clip.

7. Wear in your hair or your doll's hair.

Doll cannot stand alone.

Printer and computer not included.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com