



EN


Plug Sentina into AC Outlet charge for 12 hours.



Setting up (auto mode)




Setting up (manual mode)



Use as a flashlight


Unplug it from the socket

(Make sure that Flashlight Switch is at "Auto")



Set "FLASHLIGHT" switch

to "ON" to keep flashlight ON.



After use, please make sure to

set "FLASHLIGHT" back to "AUTO" and plug Sentina back into a power socket.

IMPORTANT!

1. Always keep Sentina on a power socket.

If Sentina is unplugged for a long time, the built-in battery may discharge completely. It may exhaust the battery and lower its performance.

2. Plug Sentina into AC 120V socket only.

In case of using Sentina in foreign country, please use proper converter.

Please visit

www.datexx.com

**For More Great Products
and Warranty Info**

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>